



TANK CIVIL

TANK SAFEVOICE

The venue speaks zone by zone. No wiring.

SafeVoice delivers audio messages to each zone of a venue, scheduled or emergency, triggered from the cloud. Welcome, farewell or evacuation, wherever they are needed.

01	02	03
Each zone hears its own message.	No wiring work.	Scheduled or emergency.
Welcome, farewell or evacuation, only where it applies.	Audio reaches each zone without running cables through the venue.	Messages on a schedule and emergency activation, from the cloud.

WHAT FOR Welcome and farewell • Scheduled announcements by zone • Evacuation and emergencies

PUBLIC SPECIFICATIONS

PARAMETER	VALUE	CONDITION
Operation		
Activation	Scheduled and emergency	From the cloud
Reach	By zone	Each zone receives its own message
Track record	In continuous operation	At a high-traffic public venue

WHAT'S INCLUDED

- Audio units for each zone
- Scheduled and emergency activation from the cloud
- Installation and maintenance by Tank



Let's talk about your site

ventas@tnk.la • tnk-defense.com/en/products/safevoice/
Tank SpA • Santiago, Chile

Specifications subject to change without notice. Public data; the full datasheet is provided to your team during the assessment. Preliminary version: values may be adjusted before version 1.0.